



OPERATING MANUAL

English

Sweepovac Kick Vac (SVP SL) & Sweepovac Big Kick (SVP BK)

**All models containing
SVP SL or SVP BK**

SAVE THESE INSTRUCTIONS

Section 1

Warning: Installation	2
Warning: Operation	3
Warning: Disposal	4

Section 2

Instructions for use	5
Changing the bag and filter	6
Whats in the box	7

Section 3

Fitting Instructions	9
Dimension Information	12

Section 4

Troubleshooting	14
Warranty	15

Section 1

IMPORTANT SAFETY INSTRUCTIONS

Dear Customer

Hi

I'm Henry, the founder of Sweepovac. I want to sincerely thank you for choosing a Sweepovac vacuum. We work hard to produce quality vacuums. Our aim is to manufacture vacuums that are very powerful and very easy to use. We hope this will make cleaning easier, more thorough and less time consuming. We would love your feedback and opinions, so please email us or post a review to let us know what you think. This helps us to continually improve our products and serve you, our customers, better.

From all at the Sweepovac team

Henry (**Founder and CEO of Sweepovac**)

IMPORTANT: PLEASE READ ALL INSTRUCTIONS BEFORE USE.
PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE.

WARNING - Do not use on wet surfaces, in wet environments or outdoors.

WARNING: Basic safety precautions should always be observed when using an electrical appliance. Please observe the safety points on the following pages to reduce the risk of fire, electrical shock, or injury.

Please read through these operating instructions carefully. Please study and observe the safety instructions on the first few pages of this booklet. Please observe all cautionary markings in this manual, on the vacuum bags and on the Sweepovac vacuum appliance. Please keep these operating instructions for later reference and pass them on to any person carrying out cleaning, maintenance or repair, or to any subsequent owner of the appliance.

Section 1

WARNING: INSTALLATION

To reduce the risk of fire, electric shock, or injury:

A1 Installation must be carried out strictly in accordance with the supplied installation instructions.

A2 *The appliance must be plugged into an outlet, located so that power can be readily removed from the appliance for the purpose of maintenance, cleaning and similar purposes.*

A3 Ensure power can be switched off at the electrical panel.

A4 Ensure any extension leads used are suitable and in good condition. Please consult an electrician if in doubt.

A5 If removal and replacement of the supplied plug-top is required for installation, it must be re-connected properly ensuring that the live and earth coloured wires are inserted correctly. PLEASE CONSULT AN ELECTRICIAN.

Always ensure that the cable clamp is fitted and that it clamps the cable outer and NOT the coloured wires.

A6 If for any reason, it becomes necessary to replace a fuse, please consult an electrician to ensure that any new fuse is fitted correctly and complies with local building codes.

A7 If the supply cable of the appliance is damaged, disconnect the appliance from the outlet immediately. **The complete Sweepovac electrical module will have to be replaced. This should be carried out by Sweepovac only, or an appointed agent.**

If in any doubt please consult a qualified electrician or Sweepovac directly

A8 Fitting Clearances:

The vacuum must have the following clearances when fitted;

Rear of the machine to nearest surface – 3/4" (20mm). Top and bottom of the body of the machine to nearest surfaces – 1/8" (3mm).

Left hand and right hand side of the machine body- collectively – 3" (75mm). The compartment that the Sweepovac is installed should not be sealed and should have a ventilation equivalent to 4" Sq (25cm Sq).

WARNING: OPERATION

To reduce the risk of fire, electric shock, or injury:

B1 The Sweepovac unit is designed to handle normal dry dust and debris in a domestic or office environment. It is not designed to handle water, or superfine industrial dust. Do not install or use the Sweepovac vacuum outdoors, in a bathroom, a wet area, within 10 feet (3.1m) of a pool. Do not expose to moisture, rain or snow. Do not pick up water or sweep water into the Sweepovac vacuum.

B2 ***Do not pick up, sweep in or vacuum water, or any other liquid.*** This will cause the product to fail, and invalidate your warranty.

Section 1

B3 It is not designed to pick up small sharp objects, such as pins, paper clips, small toys, etc.

B4 ***Do not use without a clean dust-bag and filter in place.*** To do so can damage the appliance, and invalidate your warranty.

B5 Do not operate the Sweepovac vacuum when the drawer is removed.

B6 Do not fit anything other than original Sweepovac dust bags or filters. To do so can damage the appliance, and invalidate your warranty.

B7 Always remove the plug from the wall or switch off power at the electrical panel before attempting any form of user maintenance or cleaning as specified in this booklet.

B8 This Sweepovac vacuum device is not intended for use by young children or infirm persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, unless they have been given instruction and are being supervised by a responsible person.

B9 Do not allow the Sweepovac vacuum to be used as a toy. Close attention is necessary when used by children. Children should be supervised to ensure that they do not play with the Sweepovac vacuum.

B10 Do not sweep any combustible or flammable material such as gasoline or lighter fuel into the Sweepovac.

B11 Do not sweep in anything that is burning or smoking, such as cigarettes. Do not sweep in hot or warm ashes from a stove, fireplace etc.

B12 Do not place any objects inside the Sweepovac chamber when the drawer is removed.

B13 Do not put your hand inside the Sweepovac chamber when the drawer is removed.

B14 Do not disassemble the Sweepovac vacuum as incorrect assembly may result in electric shock, malfunction or fire.

WARNING: DISPOSAL

To reduce the risk of fire, electric shock, or injury:

C1 The materials used in this product comply with international EU Directives on the Restriction of Hazardous Substances (RoHS)

C2 The symbol shown below and on the product, indicates that it is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

C3 If disposing of this product, please contact your local authority or the retailer from which the product was purchased. In the event of difficulty, please contact Sweepovac directly.



Section 2

INSTRUCTIONS FOR USE



1. Sweep dirt to a point in front of the Sweepovac.



2. Tap the lower part of the switch gently with the broom or with your foot.



3. Sweep in the dirt.



4. Plug in the flexible hose to use as a regular vacuum.

Latch for opening the drawer which contains the dust bag.



Inlet for the dirt.

On/Off switch

Section 2

CHANGING THE BAG AND FILTER



5. Slide out the bag drawer.



6. Hold the bag upright when removing to prevent dirt spilling out. Bags should be emptied every 12 weeks or when full. The entire drawer can be carried to the garbage when emptying or changing bags. When re-inserting the bag, ensure the 3 cardboard lugs are fully slotted home.



7. It is recommended to clean the filter every 12 months or if it appears dirty on visual inspection.

To clean, remove and tap to shake off excess dust. The filter may be washed gently with warm water. Leave to dry thoroughly before re-inserting.



8. Push the drawer home until it clicks back into place.

HOW DO YOU KNOW THE BAG IS FULL?

1. If it is unable to suck up all the dirt.
2. If dirt has to be brushed right into the opening to be vacuumed up.
3. If the motor sound changes.

Section 2

CONTENTS : WHATS IN THE BOX

MODEL: Sweepovac Big Kick. Model Numbers starting with : SVP BK



- | | |
|--|---|
| 1. Cut out Template | 8. Power cord - 10ft (3m) |
| 2. 4 wood screws | 9. Hanging carrier bag for hose and tools |
| 3. Telescopic vacuum pipe | 10. Upholstery cleaning brush |
| 4. Flexible Hose - 10ft - 33ft (3m to 10m) | 11. Dog grooming tool |
| 5. Sweepovac unit with re-usable bag and filter fitted | 12. Probe/Crevise tool |
| 6. 2 x spare re-usable bags | 13. Vacuum foot piece |
| 7. Manual | |

Section 2

CONTENTS : WHATS IN THE BOX

MODEL: Sweepovac Kick Vac. Model Numbers starting with: SVP SL



- | | |
|--|---|
| 1. Cut out Template | 6. Manual |
| 2. 4 wood screws | 7. Power cable |
| 3. Flexible Hose - 6ft - 18ft (1.8m to 5.5m) | 8. Upholstery tool |
| 4. Sweepovac unit with re-usable bag and filter fitted | 9. Attachable brush for upholstery tool |
| 5. 2 x spare re-usable bags | 10. Probe/Crevice tool |

Note : In some markets items 3,8,9 and 10 are not included as standard and are instead sold as a separate accessory pack.

Section 3

FITTING INSTRUCTIONS

Tools required



9. Pencil or fine point marker
1/2" to 1" drill bit
Jigsaw or Sawzall
Cut out template (included)
Philips head screwdriver No 2
Template for marking the cut out.



10. A Jigsaw or a Sawzall can be used to cut the opening.



11. Take the Sweepovac from the box. Remove the drawer and unscrew the 4 screws holding the face plate on.



12. Unclip the face plate by gently pulling it away from the body. Some force may be required and a small flat head screwdriver may be used to assist.

Section 3


IF YOUR KITCHEN CABINETRY HAS BEING SUPPLIED WITH THE SWEEPOVAC OPENING ALREADY PRE-CUT IN THE TOE KICK, THEN PLEASE PROCEED TO THE NEXT PAGE.

FITTING INSTRUCTIONS

How to fit the unit



13. Place the template against the surface and mark with a fine tipped pen.



14. Drill the corner holes.



15. For fixed end panels or fixed toe kicks, a Sawzall can be used to cut the opening.



16. For removable toe kicks, a Jigsaw can be used to cut the opening.



18. Use the levelling foot to ensure the unit will sit level when fitted.



19. Slide in the power cable and locate it beside the outlet it will be plugged into.

Section 3

FITTING INSTRUCTIONS

How to fit the unit



20. Slide in Sweepovac unit.



21. Screw into place using the 4 wood screws.



22. Clip the face plate back on to the machine and insert the 4 screws.



23. Plug the Sweepovac into a standard electrical outlet 120V (US) or 220-240V (EU)



24. Slide in the drawer ensuring that the bag and filter are in place



25. Unit is fully fitted. Well done.

Section 3



DIMENSION SHEET 1

Model Name - Sweepovac Big Kick

Model Numbers - SVP BK 1

Model Numbers - SVP BK 2

Model Numbers - SVP BK 3



Section 3



DIMENSION SHEET 2

Model Name - Sweepovac Kick Vac

Model Numbers - SVP SL 1

Model Numbers - SVP SL 2

Model Numbers - SVP SL 3



Section 4

TROUBLESHOOTING

If suction reduces or the Sweepovac does not vacuum up the sweepings.

Open the drawer and check if the bag is full. When changing the bag, make sure to hold the bag tray with the front pointing upwards. This will prevent any dirt falling back out through the opening. Replace old bag with a new bag. The filter located at the rear of the bag tray can be cleaned if it appears dirty on visual inspection. Try again.

If the Sweepovac stops operating.

The Sweepovac motor has a thermal cut out. If the motor overheats, check for blockages and wait for one hour before operating again. Check that other electrical outlets in close proximity to the Sweepovac are working. Check the electrical panel for the house.

If you accidentally operate the Sweepovac without a bag.

Unplug from the outlet. Remove the bag drawer and use the hose of a normal vacuum cleaner to clean out the internal cavity of the Sweepovac. Clean the filter and insert a new bag.

To check for and remove a blockage at the inlet aperture.

Remove the bag drawer, hold the drawer vertically with the front pointing upwards, this will allow the sweepings to fall to the rear of the bag. Lay the drawer flat, remove the bag, insert a single finger through the bag holding pipe, any obstruction will be felt and can be removed. A finger can also be inserted into the outside opening through which the dirt is vacuumed.

To check for and remove a blockage at the motor inlet.

Ensure the Sweepovac is unplugged. Remove the bag drawer. Visually inspect the rear of the cavity where the bag drawer sits. A grill at the rear protects the motor. This grill should be free from any obstruction.

If none of the above are effective.

Contact an electrical repair shop or Sweepovac if the warranty is still valid.

To remove the entire Sweepovac appliance from its location.

Consult the fitting instructions that accompanied this manual, ensure that the Sweepovac is disconnected from the power before removal.

Section 4

WARRANTY

Dear Customer,

Thank you for purchasing a Sweepovac unit. The Sweepovac unit and associated products are designed and manufactured to a high standard and with normal use should last many years. The warranty period on your Sweepovac unit is 2 years from the date of purchase. In the unlikely event of the unit not working, you will need to provide us with a copy of your proof of purchase (Invoice, sales receipt etc.). The period of warranty is calculated starting 2 weeks after this date. This is to allow for timely installation.

Warranty assistance includes: Replacement of unit if deemed faulty. Please note that the customer is responsible for the removal of the faulty unit and packaging and mailing of the unit back to Sweepovac. Sweepovac will cover the cost associated with the return of the replacement unit back to the customer.

Normal use is described in detail in the operations section of this manual. It includes : Never allowing water to come into the machine or near the electrical parts inside the machine. Ensuring that wet debris or heavy items are never vacuumed into the machine. Please ensure that the unit is installed as per installation instructions. We recommend changing or emptying the vacuum bag every 12 weeks (for normal domestic use). Please ensure that any malfunction is checked against the trouble shooting section in this manual before removal and dispatch to Sweepovac. Please contact a registered electrical contractor to replace any damaged cables immediately.

We hope you enjoy your Sweepovac

General Terms and Conditions

1. Sweepovac warrants that, when dispatched from a Sweepovac warehouse, the appliance is free from defects in materials and workmanship for the warranty period.
2. The warranty period is 24 months from the registered date of purchase.
3. The warranty only applies to products that have been installed in accordance with the enclosed Sweepovac installation instructions.
4. The warranty only applies to products that have been operated and maintained in accordance with the enclosed Sweepovac Operation/Maintenance Manual.
5. During the warranty period, Sweepovac, or its authorized agents, will, at no extra charge and subject to these terms and conditions, repair or replace any parts which it considers to be defective.
6. This warranty does not apply to dust bags, filters, accessories or similar consumable parts.
7. The warranty does not apply in the following situations:
 - A. Incomplete or improper installation.
 - B. Vacuuming of very fine dust or wet materials.
 - C. Use without recommended dust-bags or filter.
 - D. Use of non-recommended dust bags or filters.
 - E. Normal wear and tear.
 - F. Failure to properly maintain or service.
8. Proof of purchase is required before you can make a claim under this warranty.

Please visit our website to view a selection of videos on how to fit or remove a Sweepovac.

www.sweepovac.com